
به نام خدا



گزارش کار آزمایش شماره 1

حديث غفوري(9825413)


گام اول:





طبق تصویربالا ادرس سیستم 192.168.1.103 است که جز کلاس \mathbf{C} است همچنین ادرس gateway برابر 192.168.1.1 است


گام دوم:

از گام اول میدانیم ip سیستم مان 192.168.1.103 است حال مراحل را به ترتیب طبق عکس های زیر طی میکنیم . ابتدا پوشه را ایجاد کرده و در گزینه properties داریم









میبینیم طبق اخرین عکس در قسمت فایل های share شده پوشه test که ایجاد کردیم هست


گام سوم:


```
Wireless LAN adapter Wi-Fi 2:
  Connection-specific DNS Suffix .:
  Description . . . . . . . . : Intel(R) Wireless-AC 9560 160MHz #2
  Physical Address. . . . . . . : 38-DE-AD-E4-61-5F
  DHCP Enabled. . . . . . . . . .
  Autoconfiguration Enabled . . . . :
                                      192.168.1.103(Preferred)
  IPv4 Address. . . . . . . . . . . . . . .
                                      255.255.255.0
  Subnet Mask . . . .
                                      Friday, February 25, 2022 5:46:44 AM
  Lease Obtained. . . . .
                                      Saturday, February 26, 2022 5:46:43 AM
  Lease Expires . .
                                      192.168.1.1
  Default Gateway . . . .
  DHCP Server . . .
                                      192.168.1.1
  DNS Servers . . . .
                                      192.168.1.1
  NetBIOS over Tcpip. . . . . . : Enabled
```

طبق عكس بالا physical address سيستم برابر 38-DE-AD-E4-61-5F است .

ادرس DNS Server برابر DNS Server است.

با توجه به گزینه ی DHCP enabled ادرس سیستم بصورت اتوماتیک از سرور گرفته شده است حال network و سپس control panel و سپس control panel و سپس change adapter settings و میشویم و در گزینه ی change adapter settings داریم





ادرس سیستم را بصورتی دستی به 192.168.1.105 تغییر دادیم همچنین عموما gateway همان ادرس سیستم با اخرین رقم 1 است حال با دستور ipconfig در محیط خط فرمان ادرس تغییر یافته را مشاهده میکنیم

دستور ip config releaseکارت شبکه را غیر فعال میکند

```
::\WINDOWS\system32>ipconfig /release
Windows IP Configuration
No operation can be performed on Ethernet while it has its media disconnected.
No operation can be performed on Local Area Connection* 1 while it has its media disconnected.
No operation can be performed on Local Area Connection* 2 while it has its media disconnected.
Ethernet adapter Ethernet:
  Media State . . . . . . . . . : Connection-specific DNS Suffix . :
                                 . . . : Media disconnected
Wireless LAN adapter Local Area Connection* 1:
                                 . . . : Media disconnected
  Media State . . . . . . . . . : Connection-specific DNS Suffix . :
Wireless LAN adapter Local Area Connection* 2:
  Media State . . . . . . . . : : Connection-specific DNS Suffix . :
                                . . . : Media disconnected
Ethernet adapter Ethernet 3:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
Ethernet adapter VMware Network Adapter VMnet1:
  Connection-specific DNS Suffix . :
  Default Gateway . . . . . . . :
Ethernet adapter VMware Network Adapter VMnet8:
  Connection-specific DNS Suffix .:
  Default Gateway . . . . . . . :
Wireless LAN adapter Wi-Fi 2:
  Connection-specific DNS Suffix .:
  Default Gateway . . . . . . . :
 :\WINDOWS\system32>
```

بعد از اجرای این دستور با ipconfig میبینیم ادرس سیستم به 169.254.220.49 تغییر یافته است که یک ip رزور شده برای نشان دادن قطعی شبکه است و سیستم نمیتواند از DHCP سرور IP بگیرد

```
Connection-specific DNS Suffix .:

Description . . . . . . . . : Intel(R) Wireless-AC 9560 160MHz #2

Physical Address . . . . . . : 38-DE-AD-E4-61-5F

DHCP Enabled . . . . : Yes

Autoconfiguration Enabled . . . : Yes

Autoconfiguration IPv4 Address . : 169.254.220.49(Preferred)

Subnet Mask . . . . . . . . : 255.255.0.0

Default Gateway . . . . . : Enabled
```

با دستور ipconfig/renew دوباره کارت شبکه را فعال میکنیم تا دوباره سیستم از سرور ipبگیرد

```
C:\WINDOWS\system32>ipconfig /renew
Windows IP Configuration
No operation can be performed on Ethernet while it has its media disconnected.
No operation can be performed on Local Area Connection* 1 while it has its media disconnected.
No operation can be performed on Local Area Connection* 2 while it has its media disconnected.
No operation can be performed on Ethernet 3 while it has its media disconnected.
Ethernet adapter Ethernet:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
Wireless LAN adapter Local Area Connection* 1:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
Wireless LAN adapter Local Area Connection* 2:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
Ethernet adapter Ethernet 3:
  Media State . . . . . . . . . : Media disconnected Connection-specific DNS Suffix \, . :
Ethernet adapter VMware Network Adapter VMnet1:
  Connection-specific DNS Suffix .:
  IPv4 Address. . . . . . . . . : 192.168.85.1
  Subnet Mask . . . . . . . . . : 255.255.255.0
  Default Gateway . . . . . . . :
Ethernet adapter VMware Network Adapter VMnet8:
  Connection-specific DNS Suffix .:
   IPv4 Address. . . . . . . . . : 192.168.147.1
  Subnet Mask . . . . . . . . . : 255.255.255.0
  Default Gateway . . . . . . . :
Wireless LAN adapter Wi-Fi 2:
  Connection-specific DNS Suffix .:
  IPv4 Address. . . . . . . . . : 192.168.1.103
  Subnet Mask . . . . . . . . . : 255.255.255.0
  Default Gateway . . . . . . . : 192.168.1.1
```

دستور getmac فقط ادرس فیزیکی را میدهد

گام چهارم:

دستور ping ارتباط سیستم ما با یک هاست مورد نظر ما را چک میکند که برقرار است یا خیر اگر پاسخی دریافت شد به معنای برقراری ارتباط است

```
C:\Users\Win 10>ping iut.ac.ir
Pinging iut.ac.ir [176.101.52.155] with 32 bytes of data:
Reply from 176.101.52.155: bytes=32 time=42ms TTL=54
Reply from 176.101.52.155: bytes=32 time=46ms TTL=54
Reply from 176.101.52.155: bytes=32 time=47ms TTL=54
Reply from 176.101.52.155: bytes=32 time=45ms TTL=54
Ping statistics for 176.101.52.155:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 42ms, Maximum = 47ms, Average = 45ms
C:\Users\Win 10>_
```

برای سایت گوگل هم چون ارتباط برقرار است از ان هاست پاسخ میگیریم

```
C:\Users\Win 10>ping google.com
Pinging google.com [142.250.186.174] with 32 bytes of data:
Reply from 142.250.186.174: bytes=32 time=143ms TTL=57
Reply from 142.250.186.174: bytes=32 time=141ms TTL=57
Reply from 142.250.186.174: bytes=32 time=139ms TTL=57
Reply from 142.250.186.174: bytes=32 time=140ms TTL=57
Ping statistics for 142.250.186.174:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 139ms, Maximum = 143ms, Average = 140ms
C:\Users\Win 10>
```

گام پنجم:

دستور tracert به ما میگوید بسته ارسالی تا هاست مورد نظر (اینجا گوگل) چه نود ها یا روتر هایی را طی میکند تا به مقصد برسد و مشاهده میشود اولین نود همان gateway است که بسته های ارسالی سیستم ما از اولین جایی که عبور میکند این نود است

```
C:\Users\Win 10>tracert google.com
Tracing route to google.com [142.250.186.174]
over a maximum of 30 hops:
 1
        4 ms
                 3 ms
                          1 ms
                                 192.168.1.1
                24 ms
 2
       27 ms
                          27 ms
                                 10.142.33.8
       26 ms
                27 ms
                          31 ms
                                 172.16.35.81
       28 ms
                30 ms
                          27 ms
                                 172.16.34.145
 5
       26 ms
                26 ms
                          27 ms
                                 172.16.5.173
      180 ms
                46 ms
                         169 ms
                                 10.202.6.162
       52 ms
                49 ms
                         48 ms
                                 10.21.71.12
      47 ms
                46 ms
                         45 ms
                                 10.31.71.20
 9
                65 ms
                                 134.0.220.186
      68 ms
                         66 ms
 10
      156 ms
               152 ms
                         69 ms
                                 213.202.5.239
 11
       67 ms
                64 ms
                         65 ms
                                 216.239.48.133
12
       67 ms
                64 ms
                          64 ms
                                 108.170.240.57
13
                                 Request timed out.
14
                                 Request timed out.
15
      146 ms
               140 ms
                                 72.14.239.166
                         141 ms
16
                                 108.170.252.1
      175 ms
               143 ms
                         173 ms
17
      151 ms
               149 ms
                         153 ms
                                 142.250.214.203
18
      141 ms
               141 ms
                         142 ms fra24s08-in-f14.1e100.net [142.250.186.174]
Trace complete.
C:\Users\Win 10>tracert google.com
```

Time out زمانی اتفاق میکند که بسته ارسالی ما در طی مسیر یا به روتر های شلوغ برمیخورد که در صف انتظار قرار میگرد یا در مسیر گم میشود و چون هر بسته پس از یک زمان خاص در شبکه حذف میشود و دور ریخته میشود پس از پایان ان زمان Time out رخ میدهد

گام ششم:

دستور nslookup میتواند نام سرور را به ادرس ip ان تغییر دهد و به ما بدهد

سرور DNS محلی دارای ادرس زیر است

C:\WINDOWS\system32>nslookup Default Server: UnKnown Address: 192.168.1.1

C:\WINDOWS\system32>nslookup google.com

Server: UnKnown

Address: 192.168.1.1

Non-authoritative answer:

Name: google.com

Addresses: 2a00:1450:4018:809::200e

172.217.169.238

C:\WINDOWS\system32>nslookup www.yahoo.com

Server: UnKnown

Address: 192.168.1.1

Non-authoritative answer:

Name: new-fp-shed.wg1.b.yahoo.com Addresses: 2a00:1288:110:c305::1:8000

2a00:1288:110:c305::1:8001

87.248.100.215 87.248.100.216

Aliases: www.yahoo.com

گام هفتم:

arp مشاهده جدول

```
C:\Users\Win 10>arp -a
Interface: 192.168.147.1 --- 0x13
 Internet Address
                        Physical Address
                                              Type
 192.168.147.255
                        ff-ff-ff-ff-ff
                                              static
 224.0.0.22
                        01-00-5e-00-00-16
                                              static
 224.0.0.251
                       01-00-5e-00-00-fb
                                              static
                       01-00-5e-00-00-fc
 224.0.0.252
                                              static
 239.255.255.250
                        01-00-5e-7f-ff-fa
                                              static
 255.255.255.255
                        ff-ff-ff-ff-ff
                                              static
Interface: 192.168.85.1 --- 0x16
 Internet Address
                        Physical Address
                                              Type
                        ff-ff-ff-ff-ff
 192.168.85.255
                                              static
 224.0.0.22
                        01-00-5e-00-00-16
                                              static
 224.0.0.251
                        01-00-5e-00-00-fb
                                              static
                       01-00-5e-7f-ff-fa
 239.255.255.250
                                              static
                        ff-ff-ff-ff-ff
 255.255.255.255
                                              static
Interface: 192.168.1.105 --- 0x17
 Internet Address
                        Physical Address
                                              Type
                        00-5f-67-03-fa-50
 192.168.1.1
                                              dynamic
                        ff-ff-ff-ff-ff
 192.168.1.255
                                              static
                       01-00-5e-00-00-16
 224.0.0.22
                                              static
                       01-00-5e-00-00-fb
 224.0.0.251
                                              static
                       01-00-5e-00-00-fc
 224.0.0.252
                                              static
 239.255.255.250
                       01-00-5e-7f-ff-fa
                                              static
```

دستور arp –s ادرس سیستم مان را به جدول اضافه میکنیم

```
C:\WINDOWS\system32>arp -s 192.168.1.105 00-FF-86-23-BD-AB
```

حال چک میکنیم ادرس به جدول اضافه شده است یا خیر

```
Interface: 192.168.1.105 --- 0x17
  Internet Address
                         Physical Address
                                                Type
 192.168.1.1
                         00-5f-67-03-fa-50
                                                dvnamic
 192.168.1.105
                         00-ff-86-23-bd-ab
                                                static
 192.168.1.255
                         <del>++-++-++-++-++</del>
                                                static
  224.0.0.22
                         01-00-5e-00-00-16
                                                static
  224.0.0.251
                         01-00-5e-00-00-fb
                                                static
  224.0.0.252
                         01-00-5e-00-00-fc
                                                static
  239.255.255.250
                         01-00-5e-7f-ff-fa
                                                static
```

ادرس را از جدول حذف میکنیم و با دستور arp –a جدول را چک میکنیم و مشاهده میکنیم که ادرس حذف شده است

```
C:\WINDOWS\system32>arp -d 192.168.1.105
::\WINDOWS\system32>arp -a
Interface: 192.168.147.1 --- 0x13
 Internet Address
                       Physical Address
                                             Type
 192.168.147.255
                       ff-ff-ff-ff-ff
                                             static
 224.0.0.22
                       01-00-5e-00-00-16
                                             static
 224.0.0.251
                       01-00-5e-00-00-fb
                                             static
 224.0.0.252
                       01-00-5e-00-00-fc
                                             static
 239.255.255.250
                       01-00-5e-7f-ff-fa
                                             static
 255.255.255.255
                       ff-ff-ff-ff-ff
                                             static
Interface: 192.168.85.1 --- 0x16
 Internet Address
                       Physical Address
                                             Type
 192.168.85.255
                       ff-ff-ff-ff-ff
                                              static
 224.0.0.22
                       01-00-5e-00-00-16
                                              static
 224.0.0.251
                       01-00-5e-00-00-fb
                                              static
                       01-00-5e-7f-ff-fa
 239.255.255.250
                                              static
                       ff-ff-ff-ff-ff
 255.255.255.255
                                              static
Interface: 192.168.1.105 --- 0x17
                       Physical Address
 Internet Address
                                              Type
                       00-5f-67-03-fa-50
 192.168.1.1
                                             dynamic
                       ff-ff-ff-ff-ff
 192.168.1.255
                                              static
 224.0.0.22
                       01-00-5e-00-00-16
                                             static
                       01-00-5e-00-00-fb
 224.0.0.251
                                              static
                       01-00-5e-00-00-fc
 224.0.0.252
                                              static
 239.255.255.250
                       01-00-5e-7f-ff-fa
                                              static
C:\WINDOWS\system32>
```

گام هشتم:

سوکت های فعال در لایه انتقال را نشان میدهد که از طریق انها میتوان ارتباط برقرار کرد و وضعیت سوکت ها و اینکه از چه ادرس ip به چه ادرسی رفته است را نشان میدهد و در حالت established سوکت موجود اماده برقراری ارتباط است

```
C:\Users\Win 10>netstat -n
Active Connections
  Proto Local Address
                                 Foreign Address
                                                         State
                                                         ESTABLISHED
 TCP
         192.168.1.105:1036
                                 20.199.120.151:443
 TCP
         192.168.1.105:1078
                                 142.250.102.188:5228
                                                         ESTABLISHED
  TCP
         192.168.1.105:1080
                                 20.73.194.208:443
                                                         ESTABLISHED
  TCP
         192.168.1.105:1107
                                 104.26.1.74:443
                                                         ESTABLISHED
  TCP
         192.168.1.105:1112
                                 151.101.129.69:443
                                                         ESTABLISHED
  TCP
         192.168.1.105:1115
                                 151.101.12.193:443
                                                         ESTABLISHED
         192.168.1.105:1123
  TCP
                                 198.252.206.25:443
                                                         ESTABLISHED
  TCP
         192.168.1.105:1179
                                                         ESTABLISHED
                                 172.67.192.182:443
  TCP
         192.168.1.105:1185
                                 35.244.174.68:443
                                                         ESTABLISHED
  TCP
         192.168.1.105:1186
                                 34.98.67.61:443
                                                         ESTABLISHED
  TCP
         192.168.1.105:1188
                                 69.173.144.138:443
                                                         ESTABLISHED
         192.168.1.105:1211
                                 151.101.65.194:443
                                                         ESTABLISHED
 :\Users\Win 10>
```

دستور netstat –a –n تمام سوکت های لایه TCP, UDP را که در حالت شنود هستند، با اطلاعات و شماره پورت شان به عدد نشان میدهد

Top	100 160 05 1 130		, revenience	_			
TCP	192.168.85.1:139	0.0.0.0:0	LISTENING				
TCP	192.168.147.1:139	0.0.0.0:0	LISTENING				
TCP	[::]:135	[::]:0	LISTENING				
TCP	[::]:443	[::]:0	LISTENING				
TCP	[::]:445	[::]:0	LISTENING				
TCP	[::]:5357	[::]:0	LISTENING				
TCP	[::]:5432	[::]:0	LISTENING	C:\IIsens	∖Win 10>netstat -a -n		
TCP	[::]:7680	[::]:0	LISTENING	C. (03E)	WIN TOXIECTER -8 -11		
TCP	[::]:49664	[::]:0	LISTENING	Active (onnections		
TCP	[::]:49665	[::]:0	LISTENING	7100170	Silice Casils		
TCP	[::]:49666	[::]:0	LISTENING	Proto	Local Address	Foreign Address	State
TCP	[::]:49667	[::]:0	LISTENING	TCP	0.0.0.0:135	0.0.0.0:0	LISTENING
TCP	[::]:49668	[::]:0	LISTENING	TCP	0.0.0.0:443	0.0.0.0:0	LISTENING
TCP			LISTENING	TCP	0.0.0.0:445	0.0.0.0:0	LISTENING
	[::]:49669	[::]:0		TCP	0.0.0.0:902	0.0.0.0:0	LISTENING
TCP	[::]:49671	[::]:0	LISTENING	TCP	0.0.0.0:912	0.0.0.0:0	LISTENING
TCP	[::1]:8307	[::]:0	LISTENING	TCP	0.0.0.0:5040	0.0.0.0:0	LISTENING
TCP	[::1]:49670	[::]:0	LISTENING	TCP	0.0.0.0:5357	0.0.0.0:0	LISTENING
UDP	0.0.0.0:500			TCP	0.0.0.0:5432	0.0.0.0:0	LISTENING
UDP	0.0.0.0:3702			TCP	0.0.0.0:7680	0.0.0.0:0	LISTENING
UDP	0.0.0.0:3702			TCP	0.0.0.0:49664	0.0.0.0:0	LISTENING
UDP	0.0.0.0:3702			TCP	0.0.0.0:49665	0.0.0.0:0	LISTENING
UDP	0.0.0.0:3702			TCP	0.0.0.0:49666	0.0.0.0:0	LISTENING
UDP	0.0.0.0:4500			TCP	0.0.0.0:49667	0.0.0.0:0	LISTENING
UDP	0.0.0.0:5050	*:*		TCP	0.0.0.0:49668	0.0.0.0:0	LISTENING
UDP	0.0.0.0:5353	*:*		TCP	0.0.0.0:49669	0.0.0.0:0	LISTENING
UDP	0.0.0.0:5353	* *		TCP	0.0.0.0:49671	0.0.0.0:0	LISTENING
UDP	0.0.0.0:5353	* *		TCP	127.0.0.1:1001	0.0.0.0:0	LISTENING
UDP	0.0.0.0:5353			TCP	127.0.0.1:8307	0.0.0.0:0	LISTENING
UDP	0.0.0.0:5355	* *		TCP	127.0.0.1:49672	0.0.0.0:0	LISTENING
UDP	0.0.0.0:50485			TCP	192.168.1.105:139	0.0.0.0:0	LISTENING
UDP	0.0.0.0:55547			TCP	192.168.1.105:1036	20.199.120.151:443	ESTABLISHED
				TCP	192.168.1.105:1078	142.250.102.188:5228	ESTABLISHED
UDP	0.0.0.0:56635			TCP	192.168.1.105:1080	20.73.194.208:443	ESTABLISHED
UDP	0.0.0.0:60179	*:*		TCP TCP	192.168.1.105:1112	151.101.129.69:443	ESTABLISHED
UDP	0.0.0.0:61553	*:*		TCP	192.168.1.105:1115	151.101.12.193:443 198.252.206.25:443	ESTABLISHED
UDP	127.0.0.1:1900			TCP	192.168.1.105:1123 192.168.1.105:1179	172.67.192.182:443	ESTABLISHED ESTABLISHED
UDP	127.0.0.1:49664			TCP	192.168.1.105:1179	35.244.174.68:443	ESTABLISHED
UDP	127.0.0.1:52686	*:*		TCP	192.168.1.105:1186	34.98.67.61:443	ESTABLISHED
UDP	192.168.1.105:137			TCP	192.168.1.105:1254	13.89.178.27:443	ESTABLISHED
UDP	192.168.1.105:138			TCP	192.168.1.105:1255	204.79.197.203:443	ESTABLISHED
UDP	192.168.1.105:1900			TCP	192.168.85.1:139	0.0.0.0:0	LISTENING
UDP	192.168.1.105:52685			TCP	192.168.147.1:139	0.0.0.0:0	LISTENING
UDP	192.168.85.1:137			TCP	[::]:135	[::]:0	LISTENING
UDP	192.168.85.1:138			TCP	[::]:443	[::]:0	LISTENING
UDP	192.168.85.1:1900			TCP	[::]:445	[::]:0	LISTENING
UDP	192.168.85.1:52683	*:*		TCP	[::]:5357	[::]:0	LISTENING
UDP	192.168.147.1:137			TCP	[::]:5432	[::]:0	LISTENING
UDP	192.168.147.1:138			TCP	[::]:7680	[::]:0	LISTENING
UDP	192.168.147.1:1900			TCP	[::]:49664	[::]:0	LISTENING
UDP	192.168.147.1:52684	* *		TCP	[::]:49665	[::]:0	LISTENING
UDP	[::]:500			TCP	[::]:49666	[::]:0	LISTENING
UDP	[].300		_	TCD	[].49667	[].0	LISTENING

پروتو کل های استفاده شده توسط دستور netstat -p در تصویر زیر امده است TCP, UDP, TCPv6, or UDPv6

```
:\Users\Win 10>netstat /?
Displays protocol statistics and current TCP/IP network connections.
NETSTAT [-a] [-b] [-e] [-f] [-n] [-o] [-p proto] [-r] [-s] [-t] [-x] [-y] [interval]
                 Displays all connections and listening ports.
                 Displays the executable involved in creating each connection or
                 listening port. In some cases well-known executables host
                 multiple independent components, and in these cases the sequence of components involved in creating the connection
                 or listening port is displayed. In this case the executable
                 name is in [] at the bottom, on top is the component it called,
                 and so forth until TCP/IP was reached. Note that this option
                 can be time-consuming and will fail unless you have sufficient
                 permissions.
                 Displays Ethernet statistics. This may be combined with the -s
                 option.
                 Displays Fully Qualified Domain Names (FQDN) for foreign
                 addresses.
                 Displays addresses and port numbers in numerical form.
                 Displays the owning process ID associated with each connection.
                 Shows connections for the protocol specified by proto, protomay be any of: TCP, UDP, TCPv6, or UDPv6. If used with the -s
   p prote
                 IP, IPv6, ICMP, ICMPv6, TCP, TCPv6, UDP, or UDPv6. Displays all connections, listening ports, and bound
                 nonlistening TCP ports. Bound nonlistening ports may or may not
                 be associated with an active connection.
                 Displays the routing table.
                 Displays per-protocol statistics. By default, statistics are
                 shown for IP, IPv6, ICMP, ICMPv6, TCP, TCPv6, UDP, and UDPv6;
                 the -p option may be used to specify a subset of the default.
                 Displays the current connection offload state.
                 Displays NetworkDirect connections, listeners, and shared
                 endpoints.
                 Displays the TCP connection template for all connections.
                 Cannot be combined with the other options.
  interval
                 Redisplays selected statistics, pausing interval seconds
                 between each display. Press CTRL+C to stop redisplaying
                 statistics. If omitted, netstat will print the current
                 configuration information once.
```

گام نهم:

دستور زیر ادرس ما را به ادرس سوال تغییر میدهد

```
C:\WINDOWS\system32> netsh interface ip set address name="Wi-Fi 2" static 192.168.58.3 255.255.255.0 192.168.1.1
```

دستور ipconfig میتوان نشان داد که ادرس ما به ادرس سوال تغییر کرده است

```
C:\WINDOWS\system32>ipconfig
Windows IP Configuration
Ethernet adapter Ethernet:
  Media State . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
Wireless LAN adapter Local Area Connection* 2:
  Media State . . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
Ethernet adapter Ethernet 3:
  Media State . . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
Ethernet adapter VMware Network Adapter VMnet1:
  Connection-specific DNS Suffix .:
  IPv4 Address. . . . . . . . . : 192.168.85.1
  Default Gateway . . . . . . . :
Ethernet adapter VMware Network Adapter VMnet8:
  Connection-specific DNS Suffix .:
IPv4 Address....: 192.168.147.1
  Subnet Mask . . . . . . . . : 255.255.255.0
  Default Gateway . . . . . . . :
Wireless LAN adapter Wi-Fi 2:
  Connection-specific DNS Suffix .:
  IPv4 Address. . . . . . . . . : 192.168.58.3
  Subnet Mask . . . . . . . . : 255.255.255.0
  Default Gateway . . . . . . . : 192.168.1.1
```

دستور زیر دوباره از سرور ادرس دریافت میکند

ipconfig میتواند ادرس جدید دریافتی از سرور را به ما نشان دهد

```
C:\WINDOWS\system32>netsh interface ip set address "wi-fi 2" dhcp
C:\WINDOWS\system32>ipconfig
Windows IP Configuration
Ethernet adapter Ethernet:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
Wireless LAN adapter Local Area Connection* 1:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
Ethernet adapter Ethernet 3:
  Media State . . . . . . . . : Media disconnected
  Connection-specific DNS Suffix .:
Ethernet adapter VMware Network Adapter VMnet1:
  Connection-specific DNS Suffix .:
  IPv4 Address. . . . . . . . . : 192.168.85.1
  Default Gateway . . . . . . . . . . . . . . . . . .
Ethernet adapter VMware Network Adapter VMnet8:
  Connection-specific DNS Suffix .:
  IPv4 Address. . . . . . . . . : 192.168.147.1
  Subnet Mask . . . . . . . . . : 255.255.255.0
  Default Gateway . . . . . . . :
Wireless LAN adapter Wi-Fi 2:
  Connection-specific DNS Suffix .:
  IPv4 Address. . . . . . . . . : 192.168.1.103
  Subnet Mask . . . . . . . . : 255.255.255.0
  Default Gateway . . . . . . : 192.168.1.1
```

میبینیم در این فاصله چون ادرس ip ما به سیستم دیگری اختصاص داده نشده بود دوباره سرور ادرس قبلی را به ما داد

حال ادرس dns را عوض میکنیم

ادرس dns سرور به خواسته سوال تغییر کرده است

```
Wireless LAN adapter Wi-Fi 2:
  Connection-specific DNS Suffix .:
  Description . . . . . . . : Intel(R) Wireless-AC 9560 160MHz #2
  Physical Address. . . . . . . : 38-DE-AD-E4-61-5F
  DHCP Enabled. . . . . . . . : Yes
  Autoconfiguration Enabled . . . . : Yes
  IPv4 Address. . . . . . . . . : 192.168.1.103(Preferred)
  Subnet Mask . . . . . . . . . : 255.255.255.0
  Lease Obtained. . . . . . . . : Friday, February 25, 2022 5:46:43 AM
  Lease Expires . . . . . . . . : Saturday, February 26, 2022 5:46:42 AM
  Default Gateway . . . . . . . : 192.168.1.1
                                    192 168 1 1
  DHCD Sanvan
  DNS Servers . . . . . . . . . : 18.72.0.3
  NetBIOS over Topip. . . . . . . Enabled
C:\WINDOWS\system32>_
```

از سرور برای dns ادرس جدید درخواست میکنیم

```
C:\WINDOWS\system32>netsh interface ip set dns name="wi-fi 2" source=dhcp
```

ادرس جدید را چک میکنیم که به همان 192.168.1.1 بازگشته است

```
Connection-specific DNS Suffix :

Description . . . . : Intel(R) Wireless-AC 9560 160MHz #2
Physical Address . . . . : 38-DE-AD-E4-61-5F
DHCP Enabled . . : Yes
Autoconfiguration Enabled . : Yes
IPv4 Address . . . : 192.168.1.103(Preferred)
Subnet Mask . . . : 255.255.255.0
Lease Obtained . . . : Friday, February 25, 2022 5:46:43 AM
Lease Expires . . . : Saturday, February 26, 2022 5:46:43 AM
Default Gateway . . : 192.168.1.1
DHCP Server . : 192.168.1.1
DNS Servers . : 192.168.1.1
NetBIOS over Icpip . : Enabled
```